

SYRINGE ASSEMBLY

Knowing how to assemble a pre-filled syringe is an integral part of any code blue emergency. Pre-filled syringes in the medication tray are atropine, dextrose, lidocaine, epinephrine, calcium chloride, naloxone, and sodium bicarbonate. The easy-to-follow steps are listed below.

1. Open the syringe box from the side indicated
2. So that the two parts fall out into your hand, then
3. Flip off the plastic end-caps and
4. Attach the medication half to the plunger half with a push
5. And a twist until resistance is met.

